SRL-441 DNACER USER MANUAL

SRL-441 DANCER is a kind of disco light by using light beams to produce beautiful designs, which is suitable for small and middle sized entertain occasion.

I. **Technical Date:**

Name:	DANCER
Type:	SRL-441
Lamp:	OSRAM 64514 120V/300W X2
Power:	650W
Fuse:	5A/250V
Voltage:	AC 220V~240V 50Hz
Color:	6 dichroic colors
Weight:	11KG
Measurement:	L370 X W280 X H410 mm

II. **Operating Instructions:**

1. Plug unit into a controlled outlet.
2. Since the unit is sound activated, turn on the music and then set the sensitivity. Do this by adjusting the rotary control pod locate on the rear panel of the unit.

III. Bulb installation / Replacement

1. Before opening unit, make sure that the unit is cool and is not connected to any power source.
2. Remove the set of screws on the access door on the top of the unit. Lift accesses door open.
3. Install/replace halogen bulb. Make sure the bulb is in securely; do not touch the glass on the bulb with your bare hands, if you touch the glass, clean it with alcohol using a cotton ball or soft cloth.
4. Close the access doors and tighten the screws.

IV. Caution:

Never open this unit when it is hot and / or is connected to a power source.

We recommend extending the life of the unit that you use a chaser with this unit, or cycle the use of the unit by giving the unit a break after 30 minutes of continuous use.

Never use this unit in a wet and/ or dusty room.

Replace bulbs and fuse with those of proper specifications.